



























A	 4,5 × 30	36
B	 Ø 8 × 30	50
C	 3,5 × 30	24
D	 8 × 8	70
E	 3,5 × 14	104
F		08
G		08
H	 4,0 × 20	12
I	 černé	04

J		12
K	 4,5 × 25	06
L	 4,0 × 45	13
M	 Ø 8 × 40	02
N		02
O		12
P	 1x 2x 1x	01




01




B		50
C		12
O		12
M		02

02




A		06
C		12
K		06


03




L		04
---	--	----


04




L		01
---	---	----



05




A		06
---	---	----


06




L		04
A		03


07





L	 4,0 x 45	04
---	---	----


08





A	 4,5 x 30	15
---	---	----


09




A	 4,5 x 30	04
---	---	----

10






A	 4,5 x 30	02
---	---	----


11





12






D	 10 x 10	70
---	--	----







E	 3,5 × 14	16
G		08

14






E	 3,5 x 14	52
F		08




I	 	04
---	--	----

J		12
H	 4,0 x 20	12

15





E	 3,5 × 14	36
N		02




horní
deska

P- SEZNAM DÍLŮ


páska (proti převržení)
(1×)


vrut do dřeva (proti převržení)
3,5 × 25 mm (1×)


podložka (proti převržení)
(2×)

